
## How do I use the Emergency Credit when my main credit runs out?



- 2. Use the 'UP' and 'DOWN' buttons to highlight "Use Emergency Credit"
- 3. Press 'ENTER' again.

The 'Emergency Credit' will now start counting down until you next top up.



REMEMBER to top up with more than £5 so that the Emergency Credit can be reinstated and normal credit is available.